

## Quick Start

### Custom Fitting 101: How to get the best sound out of your new Earbuds and Comply Foam ear tips

1. **REMOVE** the silicone tips off the earbud first, putting on one of the three sizes foam tips included.
2. **OPEN** the Comply bag (most start with the medium size), then attach to the earbud (see illustration below).
3. **COMPRESS THE TIP:** pinch the foam ear tip into a thin, round cylinder. The foam cannot be over-compressed.
4. **MAKE A CUSTOM FIT:** immediately insert the compressed Comply ear tip and hold. Do not force, and do not insert the tip without compressing first. If the tip expands before inserting, pinch down the foam again.

**HOLD IN THE EAR:** once inserted, hold in place for a few seconds (longer for larger ear canals) while the Comply foam tip expands; creates noise isolation. **Test for Snugness:** If you slightly pull the Earbud housing (not the cord!) and it stays put, sound reproduction will be at its best.

### Features of the Remote Control/Call Answering & Music Pause Button

1. The round button Answers and Cancels calls
2. Also Pauses Music
3. Accesses Siri and Androids S-Voice. Simply press and hold. Press again to cancel.
4. Convenient Volume Control

**Volume:** Set volume to a comfortable listening level. **Warranty:** 1 year on the basic earbud. Pulling on the cord when removing the jack or removing the earbud could invalidate the warranty. **Best Results:** Keep the inside of the earphones clean at all times, and periodically wipe the jack with a clean cloth to avoid **static buildup**.

**Customer Service:** Email [info@overthetopsvcs.com](mailto:info@overthetopsvcs.com), Toll Free at 888 600-8566 PST, M-F, 8 AM TO 5 PM for any questions. Please check out our blog for **coupon deals** at <https://overthetopsvcs.com>

## Changing the Comply™ Premium Earphone Tip



Remove old tip and discard it. Clean earphone nozzle of any debris. Securely apply the new Comply™ Premium Earphone Tip onto clean, dry nozzle. Recommended replacement is after 3 months of regular use. For replacement tips, go to **complyfoam.com**.

## Inserting the Comply™ Premium Earphone Tip



1. Roll the tip into a thin, round cylinder.



2. Pull back and up on the ear to open the canal. Gently insert the entire tip into the ear.



3. Hold the tip in place until it expands.